## **Head Operating Instructions**

- 1. Head is for peeing only, unless we are cruising! Only waste and toilet paper go in the bowl.
- 2. Open lid and with valve in *Flush* position pump handle to wet bowl and put a small amount of water in the bottom.
- 3. Do your business and only use small amount of toilet paper.
- 4. With valve in *Flush* position pump handle with enough throw to bring water in the bowl and flush contents. No need to go full throw on the flushing handle as long as you see water pumping.
- 5. Pump for at least 7 times after the initial bowl contents are removed.
- 6. Rotate the valve to *Dry* then pump the bowl dry. Wait a few seconds for any residual to drain and pump again to empty bowl.
- 7. Close the lid

Valve handle must be fully in the "FLUSH" or "DRY" position only.



Position for intake of water and discharge of bowl contents



Position for discharge of bowl contents only (no water coming in)